

# PERFECT Classic/Advanced

A soft, comfortable stool with a wide surface area. The Advanced model is unisex, while the Classic model is particularly well suited for women. Height and tilt levers are positioned under the seat.

## Description

Seat height	46-86 cm
Seat dimensions	36x45 cm
Gas spring options	3
Alternative castors	Yes
Base diameter	50 cm
Adjustable seat	Yes, 15°
Upholstery	Scandinavian leather, vinyl or fabric
Weight	9 kg
Max. load	120 kg
Warranty	5 years

## Accessories

Foot ring	Foot rest while working in high chair positions
Foot control	Foot operated height adjustment
SWING arm rest	Arm rest that doubles as a back and abdominal support. Can swivel 360° for complete freedom and versatility
Lumbar support	Provides adjustable lumbar support



## Seat Heights

User height	Gas spring	Seat height	Seat height with SWING
< 160 cm	Short	46-60 cm	60-68 cm
160-175 cm	Standard	53-72 cm (standard)	67-80 cm
> 175 cm	High	60-86 cm	75-94 cm

## Key Features

### Mechanism

Two lever spring adjusted mechanism allows for adjustable height and up to 15° lateral movement.

### Seat

The frame is made with wood and moulded foam.

### Padding

Seat and back are upholstered with flexible polyurethane foam, recyclable when using a certain process.

### Upholstery

Our standard vinyl contains 91.5% PVC and 8.5% Polyamide and is fire resistant according to class 1/M-M2. The leather is high quality Scandinavian aniline or semi-aniline leather. The manufacture is certified to environmental standard SS-EN ISO 14001-1996.

### Gas spring

Columns are available in three sizes. The spring is made of polished steel in Germany using nitrogen, a sustainable gas existing in 78% of normal air. Gas springs are maintenance-free and recyclable.

### Base

Polished recyclable aluminium.

### Castors

Cores are made from polyamide 6 and tread is made of recyclable polyurethane. (Note: larger castor base is required when using SWING support arm).