

PERFECT Lite Hybrid/ Lite Hybrid Advanced

The PERFECT Lite Hybrid with the additional free-float functionality activates muscles in the lower back and abdomen. Specially designed depressions minimise discomfort.

Description

Seat height	49-89 cm
Seat dimensions	32x39 cm
Gas spring options	3
Alternative castors	Yes
Base diameter	50 cm
Adjustable seat	Free-float
Upholstery	Scandinavian leather, vinyl or fabric
Weight	9 kg
Max. load	120 kg
Warranty	5 years

Accessories

Foot ring	Foot rest while working in high chair positions
SWING arm rest	Arm rest that doubles as a back and abdominal support. Can swivel 360° for complete freedom and versatility



Seat Heights

User height	Gas spring	Seat height	Seat height with SWING
< 160 cm	Short	49-63 cm	63-71 cm
160-175 cm	Standard	56-75 cm (standard)	70-83 cm
> 175cm	High	63-89 cm	78-94 cm

Key Features

Mechanism

Patented free-float feature is lockable in the basic position with adjustable height and up to 15° lateral movement.

Seat

Unisex mould with recyclable polymer frame.

Padding

Upholstered with injection moulded polyurethane foam, recyclable when using a certain process.

Upholstery

Our standard vinyl contains 91.5% PVC and 8.5% Polyamide and is fire resistant according to class 1/M-M2. The leather is high quality Scandinavian aniline or semi-aniline leather. The manufacture is certified to environmental standard SS-EN ISO 14001-1996.

Gas spring

Columns are available in three sizes. The spring is made of polished steel in Germany using nitrogen, a sustainable gas existing in 78% of normal air. Gas springs are maintenance-free and recyclable.

Base

Polished recyclable aluminium.

Castors

Cores are made from polyamide 6 and tread is made of recyclable polyurethane. (Note: larger castor base is required when using SWING support arm).